

| <i>Adresse de décodeur stationnaire du DS54</i> | <i>Adresse de commutation - Cellule A de fonction</i> | <i>Adresse de commutation - Cellule B de fonction</i> | <i>Adresse de commutation - Cellule C de fonction</i> | <i>Adresse de commutation - Cellule D de fonction</i> | <i>Adresses Entrées</i> |
|---|---|---|---|---|-----------------------------|
| 01 | 01 | 02 | 03 | 04 | 1-1_8 |
| 02 | 05 | 06 | 07 | 08 | 1-9_16 |
| 03 | 09 | 10 | 11 | 12 | 2-1_8 |
| 04 | 13 | 14 | 15 | 16 | 2-9_16 |
| 05 | 17 | 18 | 19 | 20 | 3-1_8 |
| 06 | 21 | 22 | 23 | 24 | 3-9_16 |
| 07 | 25 | 26 | 27 | 28 | 4-1_8 |
| 08 | 29 | 30 | 31 | 32 | 4-9_16 |
| 09 | 33 | 34 | 35 | 36 | 5-1_8 |
| 10 | 37 | 38 | 39 | 40 | 5-9_16 |
| 11 | 41 | 42 | 43 | 44 | 6-1_8 |
| 12 | 45 | 46 | 47 | 48 | 6-9_16 |
| 13 | 49 | 50 | 51 | 52 | 7-1_8 |
| 14 | 53 | 54 | 55 | 56 | 7-9_16 |
| 15 | 57 | 58 | 59 | 60 | 8-1_8 |
| 16 | 61 | 62 | 63 | 64 | 8-9_16 |
| 17 | 65 | 66 | 67 | 68 | 9-1_8 |
| 18 | 69 | 70 | 71 | 72 | 9-9_16 |
| 19 | 73 | 74 | 75 | 76 | 10-1_8 |
| 20 | 77 | 78 | 79 | 80 | 10-9_16 |
| 21 | 81 | 82 | 83 | 84 | 11-1_8 |
| 22 | 85 | 86 | 87 | 88 | 11-9_16 |
| 23 | 89 | 90 | 91 | 92 | 12-1_8 |
| 24 | 93 | 94 | 95 | 96 | 12-9_16 |
| 25 | 97 | 98 | 99 | 100 | 13-1_8 |